



- Monitors Temperature & CO₂ Level in CO₂ Incubator
- Temperature Range from 22°C To 42°C
- CO₂% Range from 0% To 10%
- Alarm sent to user in the event of Low Temperature or Low CO₂ Level in Incubator
- Can also send Temperature & CO₂ level OK alarm on daily bases
- Alarm sent in form of GSM based SMS
- Maximum 5 users can be sent alarm